

PRESOAKS & DETERGENTS (HIGH pH)

Green N Clean

Product Code:

30010170
30010106

Product Application:

Pre-soak, Tire Cleaner, Wheel Cleaner

Description:

Green alkaline tire, whitewall and presoak. Green color for customer appeal. For use in conveyors, and high pressure automatics.

Dilution Recommendations:

Presoak
Tire Cleaner
Wheel Cleaner

2x
120-240:1
12-36:1
12-36:1

2x PRODUCT

- Step 1:** Fill graduated cylinder to **5ml**. Mark with solution.
- Step 2:** Add **4** drops Indicator **P**. Solution will turn Pink.
- Step 3:** Add Titrate **#2** dropwise. Invert tube to mix after each drop.
- Step 4:** Continue adding drops until solution turns colorless.

Dilution Range: 1280:1 – 100:1
Indicator: P
Titrate #: 2

| # Drops | OZ. Per Gal. | Ratio: |
|---------|--------------|--------|
| 3 | 0.10 | 1280:1 |
| 4 | 0.16 | 790:1 |
| 5 | 0.22 | 570:1 |
| 6 | 0.29 | 446:1 |
| 7 | 0.35 | 368:1 |
| 8 | 0.41 | 312:1 |
| 9 | 0.47 | 270:1 |
| 10 | 0.53 | 240:1 |
| 11 | 0.60 | 214:1 |
| 12 | 0.66 | 194:1 |
| 13 | 0.72 | 178:1 |
| 14 | 0.78 | 164:1 |
| 15 | 0.85 | 152:1 |
| 16 | 0.91 | 142:1 |
| 17 | 0.97 | 132:1 |
| 18 | 1.03 | 124:1 |
| 19 | 1.09 | 118:1 |
| 20 | 1.16 | 110:1 |
| 21 | 1.22 | 106:1 |
| 22 | 1.28 | 100:1 |

2x PRODUCT

- Step 1:** Fill graduated cylinder to **5ml**. Mark with solution.
- Step 2:** Add **4** drops Indicator **P**. Solution will turn Pink.
- Step 3:** Add Titrate **#1** drop wise. Invert tube to mix after each drop.
- Step 4:** Continue adding drops until solution turns colorless.

Dilution Range: 100:1 – 8:1
Indicator: P
Titrate #: 1

| # Drops | OZ. Per Gal. | Ratio: |
|---------|--------------|--------|
| 5 | 1.28 | 100:1 |
| 6 | 1.60 | 80:1 |
| 8 | 2.24 | 60:1 |
| 9 | 2.56 | 50:1 |
| 11 | 3.20 | 40:1 |
| 14 | 4.16 | 30:1 |
| 21 | 6.40 | 20:1 |
| 23 | 7.04 | 18:1 |
| 26 | 8.00 | 16:1 |
| 30 | 9.28 | 14:1 |
| 34 | 10.56 | 12:1 |
| 41 | 12.80 | 10:1 |
| 51 | 16.00 | 8:1 |