



Assault™

PRODUCT CODE:

94030
D109, D107, D103

DESCRIPTION:

Multi-use higher foaming alkaline presoak. Effective as either a one-step, or as a second step in two step touchless applications.

PRODUCT APPLICATION:

High Pressure, Presoak, Body Soap

DILUTION RECOMMENDATIONS:

Presoak
Tire and Wheel Cleaner

Standard

60-120:1
10-20:1

2x

120-240:1
20-40:1

STANDARD PRODUCT

- Step 1:** Fill graduated cylinder to **5 ml.** mark with solution.
- Step 2:** Add **4** drops Indicator **P.** Solution will turn pink.
- Step 3:** Add Titrate #1 dropwise. Invert tube to mix after each drop.
- Step 4:** Continue adding drops until solution turns colorless.

Dilution Range: 250:1 – 10:1
Indicator: P
Titrate #: 1

# DROPS	OZ.PER GAL.	RATIO
2	0.51	250:1
3	0.84	152:1
4	1.17	109:1
5	1.51	85:1
6	1.84	70:1
7	2.17	60:1
8	2.50	50:1
9	2.83	45:1
10	3.17	40:1
12	3.83	35:1
14	4.49	30:1
16	5.16	25:1
20	6.49	20:1
26	8.48	15:1
39	12.80	10:1

2x

- Step 1:** Fill graduated cylinder to **5 ml.** mark with solution.
- Step 2:** Add **4** drops Indicator **P.** Solution will turn pink.
- Step 3:** Add Titrate #1 dropwise. Invert tube to mix after each drop.
- Step 4:** Continue adding drops until solution turns colorless.

Dilution Range: 500:1 – 20:1
Indicator: P
Titrate #: 1



# DROPS	OZ.PER GAL.	RATIO
2	0.26	500:1
3	0.42	304:1
4	0.59	218:1
5	0.76	170:1
6	0.92	140:1
7	1.09	120:1
8	1.25	100:1
9	1.42	90:1
10	1.59	80:1
12	1.92	70:1
14	2.25	60:1
16	2.58	50:1
20	3.25	40:1
26	4.24	30:1
39	6.40	20:1