



Lift Off

PRODUCT CODE:

61030, 61015, 6105

DESCRIPTION:

High foaming, concentrated Low pH presoak. Excellent for two stage frictionless systems.

PRODUCT APPLICATION:

Presoak

DILUTION RECOMMENDATIONS:

Presoak

Standard

60-120:1

STANDARD PRODUCT

Step 1: Fill graduated cylinder to **5 ml.** mark with solution.

Step 2: Add **4** drops Indicator **P.** No color change will occur.

Step 3: Add Titrant **#3** dropwise. Invert tube to mix after each drop.

Step 4: Continue adding drops until solution turns pink.

Dilution Range: 320:1 – 50:1

Indicator: P

Titrant #: 3

<u># DROPS</u>	<u>OZ.PER GAL.</u>	<u>RATIO</u>
5	0.48	320:1
6	0.53	267:1
7	0.60	242:1
8	0.65	213:1
9	0.70	197:1
10	0.80	183:1
11	0.85	160:1
12	0.90	151:1
13	1.00	142:1
14	1.05	128:1
15	1.10	122:1
16	1.20	116:1
17	1.25	107:1
18	1.30	102:1
19	1.40	99:1
20	1.50	91:1
21	1.55	85:1
22	1.60	83:1
23	1.70	80:1
24	1.75	75:1
25	1.80	73:1
26	1.90	71:1
27	1.95	67:1
28	2.00	66:1
29	2.10	64:1
30	2.15	61:1
31	2.20	59:1
32	2.30	58:1

<u># DROPS</u>	<u>OZ.PER GAL.</u>	<u>RATIO</u>
33	2.30	56:1
34	2.30	55:1
35	2.30	53:1
36	2.30	51:1
37	2.30	50:1